

TVPROMPT

Foot Remote Control — USB —



TVP-CRP-USB

Precise control of speed, start and stop.

Forward and backward buttons of the news or indexed text

Pedal and keypad connection via XLR connectors, with wiring included.

The USB device does not need an external power outlet or adapters.

PVC frame and non-slip rubber feet

Weight: 400 grs